


LAVVU BRENNER/HELSPORT BURNER



NO: VÆR OPPMERKSOM

- Brett tilside teltgulvet under brenneren.
- Åpne topphatten helt.
- Fest brenneren til stangen slik at bunnen er maks 20 cm fra bakken.
- Legg i bunnrist - for økt lufttilstrømming.
- Unngå store flammer.

Teltduken er flammehemmende, men det kan oppstå hull ved kontakt med ild/gnister.

ENG: INSTRUCTIONS FOR USE

- Open the adjustable top-hat.
- Remove the groundsheet under the burner.
- Fasten the attachment for the burner to the pole. Place it so low that the bottom of the burner is maximum 20 cm above ground level.
- Insert the bottom grate for improved airflow.
- Avoid high flames.

The flysheet is flame retardant, but holes can occur if contact with sparks/open flame.

INNHold/INCLUDED:

- Brenner/ Stove
- Festebrakke/ Connecting bracket
- Bunnrist/ Bottom grate
- Topplukk for mulighet til matlaging/ Top plate for cooking
- Bag for transport/ Bag for transportation

INFO:

Høyde/High: 30cm
Dybde/Depth: 20cm
Vekt/Weight: 2,3kg

HELSPORT

www.helsport.no

HELSPORT AS. PB 25, N-7021 MELHUS. TLF: 72 87 83 00